

9-2350-300-20-2

TM 9-2350-300-20-2

This copy is a reprint which includes current
pages from Changes 1 through 3.

TECHNICAL MANUAL

ORGANIZATIONAL MAINTENANCE MANUAL
FOR

GUN, AIR DEFENSE ARTILLERY, SELF-PROPELLED:
20-MM, M163A1
CANNON M168, MOUNT M157A1, SIGHT M61,
AND RADAR AN/VPS-2
(NSN 2350-01-017-2113)

General Electric Company
Contract No. DAAA09-76-C-2002

This manual supersedes TM 9-2350-300-20-2, 7 April 1971, including changes.

NOTE:
Retain TM 9-2350-300-20-2, 7 April 1971, for use until conversion of M163 to
M163A1 configuration has been accomplished.

MARCH 1977

D 101.11:

best copy available

CHANGE }
NO. 3 }

TM 9-2350-300-20-2
C3
HEADQUARTERS,
DEPARTMENT OF THE ARMY
Washington, DC., 6 December 1988

Organizational Maintenance Manual

for

GUN, AIR DEFENSE ARTILLERY, SELF-PROPELLED:
20-MM, M163A1
CANNON M168, MOUNT M157A1, SIGHT M61,
AND RADAR AN/VPS-2
(NSN 2350-01-017-2113)

TM 9-2350-300-20-2, 31 March 1977, is changed as follows:

1. Remove old pages and insert new pages as indicated below.
2. New or changed material is indicated by a vertical bar in the margin of the page.
3. Revised illustrations are indicated by a vertical bar after the schematic figure title and by shaded lines in the affected areas.

Remove pages

Insert Pages

i and ii	i and ii
1-11/(1-12 blank)	1-11/(1-12 blank)
1-15/(1-16 blank)	1-15/(1-16 blank)
1-17/(1-18 blank)	1-17/(1-18 blank)
1-99/(1-100 blank)	1-99/(1-100 blank)
1-107 thru 1-109/(1-110 blank)	1-107 thru 1-110
1-111 and 1-112	1-111 and 1-112
1-113 and 1-114	1-113/(1-114 blank)
None	1-114.1/(1-114.2)
None	1-114.3/(1-114.4 blank)
1-117/(1-118 blank)	1-117/(1-118 blank)
1-125/(1-126 blank)	1-125/(1-126 blank)
1-195/(1-196 blank)	1-195/(1-196 blank)
1-201/(1-202 blank)	1-201/(1-202 blank)

4. File this change in front of this publication for reference purposes

By Order of the Secretary of the Army:

CARL E. VUONO
General, United States Army
Chief of Staff

Official:

WILLIAM J. MEEHAN II
Brigadier General, United States Army
The Adjutant General

DISTRIBUTION:

To be distributed in accordance DA Form 12-37, Unit Maintenance Requirements
for Gun, Air Defense, 20-MM, S-P, M163, M163A1.

CHANGE }
NO. 2 }

TM 9-2350-300-20-2
C2

HEADQUARTERS,
DEPARTMENT OF THE ARMY
Washington, D.C., 6 August 1985

By Order of the Secretary of the Army:

JOHN A. WICKHAM, JR.
General, United States Army
Chief of Staff

Official:

DONALD J. DELANDRO
Brigadier General, United States Army
The Adjutant General

Organizational Maintenance Manual

for

GUN, AIR DEFENSE ARTILLERY, SELF-PROPELLED:
20-MM, M163A1
CANNON M168, MOUNT M157A1, SIGHT M61,
AND RADAR AN/VPS-2
(NSN 2350-01-017-2113)

DISTRIBUTION:

To be distributed in accordance with DA Form 12-37, Organizational Maintenance requirements for Gun, Air Defense, 20-MM, Self-Propelled M163, M163A1.

TM 9-2350-300-20-2, 31 March 1977, is changed as follows:

1. Remove old pages and insert new pages as indicated below.
2. New or changed material is indicated by a vertical bar in the margin of the page.
3. Revised illustrations are indicated by a vertical bar adjacent to the illustration identification number, and shaded lines in the affected areas. Added illustrations are indicated by shaded lines around the entire new figure.

Remove pages

Insert Pages

A/(B blank)	None
i and ii	i and ii
1-3/(1-4 blank) through 1-7/(1-8 blank)	1-3/(1-4 blank) through 1-7/(1-8 blank)
1-11/(1-12 blank) through 1-13/(1-14 blank)	1-11/(1-12 blank) through 1-13/(1-14 blank)
1-17/(1-18 blank)	1-17/(1-18 blank)
1-21/(1-22 blank) through 1-35/(1-36 blank)	1-21/(1-22 blank) through 1-35/(1-36 blank)
1-39/(1-40 blank) through 1-43/(1-44 blank)	1-39/(1-40 blank) through 1-43/(1-44 blank)
1-49/(1-50 blank)	1-49/(1-50 blank)
1-55/(1-56 blank)	1-55/(1-56 blank)
1-63/(1-64 blank) through 1-65/(1-66 blank)	1-63/(1-64 blank) through 1-65/(1-66 blank)
1-69/(1-70 blank) through 1-71/(1-72 blank)	1-69/(1-70 blank) through 1-71/(1-72 blank)
1-81 through 1-83/(1-84 blank)	1-81 through 1-83/(1-84 blank)
1-91/(1-92 blank)	1-91/(1-92 blank)
1-95/(1-96 blank)	1-95/(1-96 blank)
1-101/(1-102 blank) through 1-105/(1-106 blank)	1-101/(1-102 blank) through 1-105/(1-106 blank)
1-111 through 1-114	1-111 through 1-114
1-119/(1-120 blank) through 1-121/(1-122 blank)	1-119/(1-120 blank) through 1-121/(1-122 blank)
1-125/(1-126 blank) through 1-129/(1-130 blank)	1-125/(1-126 blank) through 1-129/(1-130 blank)
1-137/(1-138 blank)	1-137/(1-138 blank)
1-141/(1-142 blank) through 1-143/(1-144 blank)	1-141/(1-142 blank) through 1-143/(1-144 blank)
1-147/(1-148 blank) through 1-149/(1-150 blank)	1-147/(1-148 blank) through 1-149/(1-150 blank)
1-159/(1-160 blank) through 1-167/(1-168 blank)	1-159/(1-160 blank) through 1-167/(1-168 blank)
1-175/(1-176 blank)	1-175/(1-176 blank)
1-179/(1-180 blank) through 1-181/(1-182 blank)	1-179/(1-180 blank) through 1-181/(1-182 blank)
1-187/(1-188 blank) through 1-201/(1-202 blank)	1-187/(1-188 blank) through 1-201/(1-202 blank)

4. File this change sheet in front of this publication for reference purposes.

CHANGE }
No 1. }

TM 9-2350-300-20-2
C-1

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, DC, 18 April 1983

Organizational Maintenance Manual
for

GUN, AIR DEFENSE ARTILLERY, SELF-PROPELLED:
20-MM, M163A1
CANNON M168, MOUNT M157A1
AND SIGHT M61 AND RADAR AN/VPS-2
NSN 2350-01-017-2113

By Order of the Secretary of the Army:

Official:

ROBERT M. JOYCE
Major General, United States Army
The Adjutant General

E. C. MEYER
General, United States Army
Chief of Staff

TM 9-2350-300-20-2, 31 March 1977, is changed as follows:

1. Remove old pages and insert new pages as indicated below. Added or revised illustrations are indicated by a vertical bar adjacent to the illustration identification number, and shaded lines in the affected areas.

Remove Pages
A/ (B blank)
1-51/(1-52 blank)
1-131/(1-132 blank)
1-153/(1-154 blank)
1-177/(1-178 blank)

Insert Pages
A/(B blank)
1-51/(1-52 blank)
1-131/(1-132 blank)
1-153/(1-154 blank)
1-177/(1-178 blank)

TM 9-2350-300-20-2, C1

DISTRIBUTION:

To be distributed in accordance with DA Form 12-37, Organizational Maintenance requirements for Gun, 20mm, XM163.

2. File this change sheet in front of the publication for reference purposes.

Reproduction for non-military use of the information or illustrations contained in this publication is not permitted. The policy for military use reproduction is established for the Army in AR 380-5, for the Navy and Marine Corps in OPNAVINST 5510.1B, and for the Air Force in Air Force Regulation 205-1.

LIST OF EFFECTIVE PAGES

Insert latest changed pages; dispose of superseded pages in accordance with applicable regulations.

NOTE: On a changed page, the portion of the text affected by the latest change is indicated by a vertical line, or other change symbol, in the outer margin of the page. Changes to wiring diagrams are indicated by shaded areas.

Total number of pages in this manual is 206 consisting of the following:

Page No.	# Change No.	Page No.	# Change No.	Page No.	# Change No.
Title	0	1-29	0	1-60 blank	0
A	1	1-30 blank	0	1-61	0
i - ii	0	1-31	0	1-62 blank	0
1-1	0	1-32 blank	0	1-63	0
1-2 blank	0	1-33	0	1-64 blank	0
1-3	0	1-34 blank	0	1-65	0
1-4 blank	0	1-35	0	1-66 blank	0
1-5	0	1-36 blank	0	1-67	0
1-6 blank	0	1-37	0	1-68 blank	0
1-7	0	1-38 blank	0	1-69	0
1-8 blank	0	1-39	0	1-70 blank	0
1-9	0	1-40 blank	0	1-71	0
1-10 blank	0	1-41	0	1-72 blank	0
1-11	0	1-42 blank	0	1-73	0
1-12 blank	0	1-43	0	1-74 blank	0
1-13	0	1-44 blank	0	1-75 - 1-82	0
1-14 blank	0	1-45	0	1-83	0
1-15	0	1-46 blank	0	1-84 blank	0
1-16 blank	0	1-47	0	1-85	0
1-17	0	1-48 blank	0	1-86 blank	0
1-18 blank	0	1-49	0	1-87	0
1-19	0	1-50 blank	0	1-88 blank	0
1-20 blank	0	1-51	1	1-89	0
1-21	0	1-52 blank	0	1-90 blank	0
1-22 blank	0	1-53	0	1-91	0
1-23	0	1-54 blank	0	1-92 blank	0
1-24 blank	0	1-55	0	1-93	0
1-25	0	1-56 blank	0	1-94 blank	0
1-26 blank	0	1-57	0	1-95	0
1-27	0	1-58 blank	0	1-96 blank	0
1-28 blank	0	1-59	0	1-97	0

Zero in this column indicates an original page.

Page No.	# Change No.	Page No.	# Change No.	Page No.	# Change No.
1-98 blank	0	1-136 blank	0	1-170 blank	0
1-99	0	1-137	0	1-171	0
1-100 blank	0	1-138 blank	0	1-172 blank	0
1-101	0	1-139	0	1-173	0
1-102 blank	0	1-140 blank	0	1-174 blank	0
1-103	0	1-141	0	1-175	0
1-104 blank	0	1-142 blank	0	1-176 blank	0
1-105	0	1-143	0	1-177	1
1-106 blank	0	1-144 blank	0	1-178 blank	0
1-107 - 1-108	0	1-145	0	1-179	0
1-109	0	1-146 blank	0	1-180 blank	0
1-110 blank	0	1-147	0	1-181	0
1-111 - 1-114	0	1-148 blank	0	1-182 blank	0
1-115	0	1-149	0	1-183	0
1-116 blank	0	1-150 blank	0	1-184 blank	0
1-117	0	1-151	0	1-185	0
1-118 blank	0	1-152 blank	0	1-186 blank	0
1-119	0	1-153	1	1-187	0
1-120 blank	0	1-154 blank	0	1-188 blank	0
1-121	0	1-155	0	1-189	0
1-122 blank	0	1-156 blank	0	1-190 blank	0
1-123	0	1-157	0	1-191	0
1-124 blank	0	1-158 blank	0	1-192 blank	0
1-125	0	1-159	0	1-193	0
1-126 blank	0	1-160 blank	0	1-194 blank	0
1-127	0	1-161	0	1-195	0
1-128 blank	0	1-162 blank	0	1-196 blank	0
1-129	0	1-163	0	1-197	0
1-130 blank	0	1-164 blank	0	1-198 blank	0
1-131	1	1-165	0	1-199	0
1-132 blank	0	1-166 blank	0	1-200 blank	0
1-133	0	1-167	0	1-201	0
1-134 blank	0	1-168 blank	0	1-202 blank	0
1-135	0	1-169	0		

Technical Manual
TM 9-2350-300-20-2

HEADQUARTERS,
DEPARTMENT OF THE ARMY
Washington, D.C., 31 March 1977

Organizational Maintenance Manual
for

GUN, AIR DEFENSE ARTILLERY, SELF-PROPELLED:

20-MM, M163A1

CANNON M168, MOUNT M157A1, SIGHT M61,

AND RADAR AN/VPS-2

(NSN 2350-01-017-2113)

REPORTING OF ERRORS

You can improve this manual by recommending improvements using DA Form 2028 (Recommended Changes to Publications and Blank Forms) or DA Form 2028-2 located in back of the manual and mailing the form direct to Commander, US Army Armament, Munitions and Chemical Command, Attn: AMSMC-MAS, Rock Island, IL 61299-6000. A reply will be furnished directly to you.

NOTE

This manual consists of two volumes: TM 9-2350-300-20-1 and TM 9-2350-300-20-2. This volume contains all applicable functional schematics and wiring diagrams. All other material is contained in TM 9-2350-300-20-1.

LIST OF SCHEMATICS

Number	Title	Page
S-1	M163A1 system overall simplified block diagram	1-1
S-2	Cannon control and firing circuits schematic diagram	1-3
S-3	Cannon control and firing circuits functional diagram	1-5
S-4	Gun clearing circuits functional diagram	1-7
S-5	Mount system block diagram	1-9
S-6	Mount elevation control functional diagram	1-11
S-7	Mount azimuth control functional diagram	1-13
S-8	Mount hatch protection circuit diagram (sheet 1 of 2)	1-15
S-8	Mount hatch protection circuit diagram (sheet 2 of 2)	1-17
S-9	Sight magnet current circuits simplified block diagram	1-19
S-10	Sight magnet current circuits functional diagram	1-21
S-11	Sight torque current circuits simplified block diagram	1-23
S-12	Sight torque current circuits functional diagram	1-25
S-13	Ten-second time delay circuit functional diagram	1-27
S-14	Acquisition time delay circuit functional diagram	1-29
S-15	Ready-to-fire circuit functional diagram	1-31
S-16	External range control circuit functional diagram	1-33
S-17	Mode scaling functional diagram	1-35
S-18	Electronic countermeasure detection circuit functional diagram	1-37
S-19	Self test circuit functional diagram	1-39
S-20	Low voltage protection circuit functional diagram	1-41
S-21	Radar set AN/VPS-2 functional block diagram	1-43
S-22	Synchronizing system functional block diagram	1-43
S-23	Synchronizing system timing diagram	1-45
S-24	Transmitting system functional block diagram	1-47
S-25	RF system functional block diagram	1-49
S-26	Receiving system functional block diagram	1-51
S-27	Sum and difference gate signals waveform diagram	1-53
S-28	Output of sum and difference gates waveform diagram	1-53
S-29	Ranging system functional block diagram (sheet 1 of 2)	1-55
S-29	Ranging system functional block diagram (sheet 2 of 2)	1-57
S-30	Elevation servo drive functional block diagram	1-59
S-31	Traverse servo drive functional block diagram	1-61
S-32	Radar power system functional block diagram	1-63
S-33	Radar configuration for clutter lock-on functional block diagram	1-65
S-34	Radar configuration for midrange calibration functional block diagram	1-65
S-35	Sight mechanism diagram	1-67
S-36	Sight and radar interface functional diagram	1-69
S-37	Battery charging circuit functional diagram	1-71
S-38	System simplified interconnection diagram	1-73
S-39	Detailed interconnection diagram (sheet 1 of 20)	1-75
S-39	Detailed interconnection diagram (sheet 2 of 20)	1-76
S-39	Detailed interconnection diagram (sheet 3 of 20)	1-77
S-39	Detailed interconnection diagram (sheet 4 of 20)	1-78
S-39	Detailed interconnection diagram (sheet 5 of 20)	1-79
S-39	Detailed interconnection diagram (sheet 6 of 20)	1-80

* This manual supersedes TM 9-2350-300-20-2, 7 April 1971, including all changes.

LIST OF SCHEMATICS (Continued)¹

Number	Title	Page
S-39	Detailed interconnection diagram (sheet 7 of 20)	1-81
S-39	Detailed interconnection diagram (sheet 8 of 20)	1-82
S-39	Detailed interconnection diagram (sheet 9 of 20)	1-83
S-39	Detailed interconnection diagram (sheet 10 of 20)	1-85
S-39	Detailed interconnection diagram (sheet 11 of 20)	1-87
S-39	Detailed interconnection diagram (sheet 12 of 20)	1-89
S-39	Detailed interconnection diagram (sheet 13 of 20)	1-91
S-39	Detailed interconnection diagram (sheet 14 of 20)	1-93
S-39	Detailed interconnection diagram (sheet 15 of 20)	1-95
S-39	Detailed interconnection diagram (sheet 16 of 20)	1-97
S-39	Detailed interconnection diagram (sheet 17 of 20)	1-99
S-39	Detailed interconnection diagram (sheet 18 of 20)	1-101
S-39	Detailed interconnection diagram (sheet 19 of 20)	1-103
S-39	Detailed interconnection diagram (sheet 20 of 20)	1-105
S-40	Cable assembly W1 wiring diagram	1-107
S-41	Cable assembly W2 wiring diagram	1-107
S-42	Cable assembly W3 wiring diagram	1-107
S-43	Cable assembly W4 wiring diagram	1-108
S-44	Cable assembly W5 wiring diagram	1-108
S-45	Cable assembly W6 and shorting connector wiring diagram	1-109
S-46	Cable assembly W7 wiring diagram	1-109
S-47	Cable assembly W8 wiring diagram	1-110
S-48	Cable assembly W9 wiring diagram	1-111
S-49	Cable assembly W10 wiring diagram	1-111
S-50	Cable assembly W11 wiring diagram	1-112
S-51	Cable assembly W12 wiring diagram	1-112
S-52	Cable assembly W13 wiring diagram	1-112
S-53	Cable assembly W14 wiring diagram	1-113
S-54	Cable assembly W17 wiring diagram	1-113
S-55	Cable assembly W101 wiring diagram	1-113
S-56	Cable assembly W102 wiring diagram	1-113
S-57	Cable assembly W103 wiring diagram	1-114.1
S-58	Cable assembly W104 wiring diagram	1-114.1
S-59	Cable assembly W105 wiring diagram	1-114.1
S-60	Cable assembly W106 wiring diagram	1-114.3
S-61	Cable assembly W107 wiring diagram	1-114.3
S-62	Cable assembly W108 wiring diagram	1-114.3
S-63	Cable routing (sheet 1 of 5)	1-115
S-63	Cable routing (sheet 2 of 5)	1-117
S-63	Cable routing (sheet 3 of 5)	1-119
S-63	Cable routing (sheet 4 of 5)	1-121
S-63	Cable routing (sheet 5 of 5)	1-123
S-64	Interface wiring diagram, M157A1 mount and M741 chassis	1-125
S-65	Slip ring assembly wiring diagram	1-125
S-66	Radar set AN/VPS-2 simplified functional schematic (sheet 1 of 4)	1-127
S-66	Radar set AN/VPS-2 simplified functional schematic (sheet 2 of 4)	1-129
S-66	Radar set AN/VPS-2 simplified functional schematic (sheet 3 of 4)	1-131

LIST OF SCHEMATICS (Continued)

Number	Title	Page
S-66	Radar set AN/VPS-2 simplified functional schematic (sheet 4 of 4)	1-133
S-67	Radar 6.5-volt and 5-volt power distribution functional schematic diagram (sheet 1 of 2)	1-135
S-67	Radar 6.5-volt and 5-volt power distribution functional schematic diagram (sheet 2 of 2)	1-137
S-68	Radar 23-volt and 15-volt power distribution functional schematic diagram (sheet 1 of 2)	1-139
S-68	Radar 23-volt and 15-volt power distribution functional schematic diagram (sheet 2 of 2)	1-141
S-69	Radar 24-volt power distribution functional schematic diagram (sheet 1 of 2)	1-143
S-69	Radar 24-volt power distribution functional schematic diagram (sheet 2 of 2)	1-145
S-70	Radar 28-volt power distribution functional schematic diagram (sheet 1 of 2)	1-147
S-70	Radar 28-volt power distribution functional schematic diagram (sheet 2 of 2)	1-149
S-71	Radar 33-volt and 25-volt power distribution functional schematic diagram (sheet 1 of 2)	1-151
S-71	Radar 33-volt and 25-volt power distribution functional schematic diagram (sheet 2 of 2)	1-153
S-72	Radar antenna positioning system functional schematic diagram (sheet 1 of 2)	1-155
S-72	Radar antenna positioning system functional schematic diagram (sheet 2 of 2)	1-157
S-73	Radar synchronizing system functional schematic diagram (sheet 1 of 2)	1-159
S-73	Radar synchronizing system functional schematic diagram (sheet 2 of 2)	1-161
S-74	Radar transmitting system functional schematic diagram (sheet 1 of 2)	1-163
S-74	Radar transmitting system functional schematic diagram (sheet 2 of 2)	1-165
S-75	RF system functional schematic diagram (sheet 1 of 2)	1-167
S-75	RF system functional schematic diagram (sheet 2 of 2)	1-169
S-76	Radar receiving system functional schematic diagram (sheet 1 of 4)	1-171
S-76	Radar receiving system functional schematic diagram (sheet 2 of 4)	1-173
S-76	Radar receiving system functional schematic diagram (sheet 3 of 4)	1-175
S-76	Radar receiving system functional schematic diagram (sheet 4 of 4)	1-177
S-77	Radar ranging system functional schematic diagram (sheet 1 of 6)	1-179
S-77	Radar ranging system functional schematic diagram (sheet 2 of 6)	1-181
S-77	Radar ranging system functional schematic diagram (sheet 3 of 6)	1-183
S-77	Radar ranging system functional schematic diagram (sheet 4 of 6)	1-185
S-77	Radar ranging system functional schematic diagram (sheet 5 of 6)	1-187
S-77	Radar ranging system functional schematic diagram (sheet 6 of 6)	1-189
S-78	M163A1 system electrical schematic diagram (sheet 1 of 5)	1-191
S-78	M163A1 system electrical schematic diagram (sheet 2 of 5)	1-193
S-78	M163A1 system electrical schematic diagram (sheet 3 of 5)	1-195
S-78	M163A1 system electrical schematic diagram (sheet 4 of 5)	1-197
S-78	M163A1 system electrical schematic diagram (sheet 5 of 5)	1-199
S-79	M163A1 interconnection schematic	1-201





Figure S-1. M163A1 system overall simplified block diagram.

AR 904960



AMC84 1110

Figure S-2. Cannon control and firing circuits schematic diagram.




Figure S-3. Cannon control and firing circuits functional diagram.

AMC84-1111





Figure S-4 Gun clearing circuits functional diagram.

AMC84-1112



AR 904968

Figure S-5. Mount system block diagram.

NOTES

1. ELEVATION LIMIT SWITCH
A18 CONDITIONS:
a. S1 ABOVE 18°
b. S2 ABOVE 13°
c. S3 ABOVE 5°
d. S4 BELOW 80°
e. S5 BELOW 80°




Figure S-6 Mount elevation control functional diagram.

NOTES:

1. ELEVATION LIMIT SWITCH
A18 CONDITIONS:
- S1 ABOVE 18°
 - S2 ABOVE 13°
 - S3 ABOVE -5°
 - S4 BELOW 80°
 - S5 BELOW 80°




Figure S-6. Mount elevation control functional diagram

AMC84-1113

Change 2

1-11/(1-12 blank)




Figure S-7. Mount azimuth control functional diagram.

AMC84-1114 ■




Figure S-8. Mount hatch protection circuit diagram (sheet 1 of 2). ■







Figure S-8 Mount hatch protection circuit diagram (sheet 2 of 2). ■



AR 904975

Figure S-9. Sight magnet current circuits simplified block diagram.



AMC84 1069

Figure S-10. Sight magnet current circuits functional diagram




Figure S-12. Sight torque current circuits functional diagram.

AMC84-1071





Figure S-13. Ten-second time delay circuit functional diagram.



AMC84 1073 ■

Figure S-14. Acquisition time delay circuit functional diagram.




Figure S-15. Ready-to-fire circuit functional diagram.

AMC84-1074





Figure S-16 External range control circuit functional diagram.



AMC84-1076

Figure S-17. Mode scaling functional diagram.





Figure S-18. Electronic countermeasure detection circuit functional diagram.



AMC84 1077

Figure S-19. Self test circuit functional diagram.




Figure S-20. Low voltage protection circuit functional diagram.




Figure S-21. Radar set AN/VPS-2 functional block diagram.





Figure S-22. Synchronizing system functional block diagram.



AR 905069

Figure S-23. Synchronizing system timing diagram.




Figure S-24. Transmitting system functional block diagram.

AR 905070





Figure S-25. RF system functional block diagram.



AR 905072

Figure S-26. Receiving system functional block diagram.




Figure S-27. Sum and difference gate signals waveform diagram.




Figure S-28. Output of sum and difference gates waveform diagram.





Figure S-29. Ranging system functional block diagram (sheet 1 of 2).

Change 2

AMC84-1080

1-55/(1-56 blank)



AR 905076

Figure S-29. Ranging system functional block diagram (sheet 2 of 2).




Figure S-30. Elevation servo drive functional block diagram.





Figure S-31. Traverse servo drive functional block diagram.



AMC84 1081

Figure S-32. Radar power system functional block diagram.

Change 2

1-63/11-64 blank




Figure S-33. Radar configuration for clutter lock-on functional block diagram.





Figure S-34. Radar configuration for midrange calibration functional block diagram.



AR 905082

Figure S-35. Sight mechanism diagram.




Figure S-36. Sight and radar interface functional diagram.




Figure S-37. Battery charging circuit functional diagram.

AMC84-1118 ■




Figure S-38. System simplified interconnection diagram.

AR 905084

NOTES FOR FIGURE S-39

1. The following symbols and the applicable pin letter are used to define test points:

⊗ Distribution Box (A1) ⊙ Control Assembly (A2)

○ Sight Current Generator (A21)

2. Circuits are shown with relay coils deenergized and no ammunition in the drum.

3. Polarity data and conventions:

- a. Motors viewed from brake end.
- b. Potentiometers (POT) and tachometers (TACH) viewed from shaft end.
- c. Tachometer polarity shown when driven counterclockwise (CCW).
- d. Clockwise (CW) and CCW refer to potentiometer, tachometer, and motor rotation.
- e. Right, left, up and down refer to cannon movement.

4. Battery low rate battery taps are moved to 10.1 volts at or below 32°F.

5. Time delay tolerances:

BURST LIMIT TIMING CIRCUITS-DELAY TIMES AND TOLERANCES

Firing rate switch A2A1S4 position	Firing time (sec)	
	Minimum delay	Maximum delay
LO-NO BURST LIMIT	0.12	0.16
HI-BURST LIMIT - 10 rounds	0.29	0.31
HI-BURST LIMIT - 30 rounds	0.67	0.78
HI-BURST LIMIT - 60 rounds	1.17	1.39
HI-BURST LIMIT - 100 rounds	1.82	2.20

RELAY DROPOUT DELAY TIMES AND TOLERANCES

Relay functions	Relay no.	Time from	Minimum delay (sec)	Maximum delay (sec)
Firing volts	A1K6	Trigger release	0.5	1.0
Low time delay	A1K9	Trigger release	0.14	0.18
Clearing	A1K11	Trigger release	2.0	3.0
Last round (INOPERATIVE)	A1K12			

M163A1 SYSTEM
COMPONENT REFERENCE LIST

COMPONENT REFERENCE DESIGNATION	COMPONENT	ZONE
A1	DISTRIBUTION BOX (see distribution box list for individual components)	49-107
A2	CONTROL PANEL (see control panel list for individual components)	45-47A-J
A3	M61 SIGHT	28-36A, B
A4	BATTERY ASSEMBLY (SYSTEM BATTERY A4A3 and GUN BATTERIES A4A1 and A4A2)	7-12A
A5	INVERTER	1G-J
A6	GUN DRIVE ASSEMBLY	3-7A
A6A1	FIRING (VOLTS) PIN (FIRING CONTACT ASSEMBLY)	3A
A6A2	GUN MOTOR AND BRAKE	6A
A6A3	DE-CLUTCHING SOLENOID	4A
A6A4	BRAKE-CLEAR AND BRAKE SWITCH	4, 5A
A7	DRUM ASSEMBLY	72, 75E
A7A1	DRUM FULL SWITCH	74E
A7A2	LOADING UNIT SWITCHES (CONVEYOR DETECTION ASSEMBLY)	73E
A7A3	LOADING MOTOR SWITCH	73E
A7A4	LOADING MOTOR	75E
A7A5	LAST ROUND SWITCH (INOPERATIVE)	
A7A6	ROUNDS COUNTER	72E
A8A1	ARM-SAFE (SHORT) SWITCH AND LEAD ASSEMBLY	4C, D
A8A3	ARMING CONNECTOR	3C, D
A9	COMMUNICATIONS (OUTSIDE)	109-123D, E
A10	EXTERNAL RANGE CONTROL	110-112A-D
A11S1	DRIVER'S HATCH SWITCH	114A
A11S2	COMMANDER'S HATCH SWITCH	115C
A12	VEHICLE POWER	109D
A13	AUXILIARY POWER	109D

AR 905496

Figure S-39. Detailed interconnection diagram (sheet 1 of 20).

M163A1 SYSTEM
COMPONENT REFERENCE LIST - CONT.

COMPONENT REFERENCE DESIGNATION	COMPONENT	ZONE
A14	SLIP RING ASSEMBLY	108-123E, F
A14S1	GUN POSITION SWITCH	113C
A15A1	AZ AMPLIFIER 1	86-89A
A15A2	AZ AMPLIFIER 2	80-84A
A15A3	EL AMPLIFIER	78-80A
A16A1	EL MOTOR	77A
A16A2	EL TACHOMETER	90A
A17A1	AZ MOTOR 1	84-85A
A17A2	AZ MOTOR 2	80-81A
A17A3	AZ TACHOMETER	89A
A18	EL LIMIT SWITCHES	99-101A-C
A19	AZ LIMIT SWITCHES	102A-C
A21	SIGHT CURRENT GENERATOR	10D
A23	COSINE E POT (ELEVATION POT)	17C
	NOTE	
	AN/VPS-2 Radar set components carry a system component designation and a radar set unit number. The following list identifies the system component designation to the radar unit number.	
A22	(UNIT 6) DISTRIBUTION BOX (commonly referred to as the STOW CONTROL)	18-22A-C
A24	FOOT SWITCH	6J
A25	(UNIT 5) POWER SUPPLY	6, 7E
A26	(UNIT 4) RANGE COMPUTER	6, 7G
A27	(UNIT 3) RECEIVER	4, 5H
A28	(UNIT 2) RECEIVER - TRANSMITTER	4, 5J
A29	(UNIT 1) ANTENNA	19-21A,B
AP35	CAGING SWITCH (and shorting connector)	36 C-D
A3DS1	M61 SIGHT RETICLE LAMP	36B
A3DS2	M61 SIGHT READY-TO-FIRE INDICATOR	36B
	AZIMUTH INDICATOR ASSEMBLY	74, 75C
	GUNNER'S LIGHT ASSEMBLY	74, 75B

RELAYS AND THEIR FUNCTIONS

RELAY		FUNCTION
	DISTRIBUTION BOX (A1)	
A1K1	LOADING	Actuates loading motor A7A4 when loading motor switch A7A3S2 is actuated.
A1K2	SYSTEM POWER	Applies power to gun control and fire control circuits, and the inverter (A5).
A1K3	ACTION	Applies power to the GUN CLEAR switch A2A1S3, action switch command relay A21K22, and the TRIGGER Switch A2A4S2 circuitry.
A1K4	TURRET POWER	Applies power to the M157 mount control components.
A1K5	TRIGGER	Applies power to the gun motor brake A6A2L1, gun motor high relay A1K8, firing volts relay A1K6, and to the burst limit control circuitry.
A1K6	FIRING VOLTS	Applies firing voltage from the converter A1A3 to the firing (Volts) pin (firing contact assembly) A6A1.
A1K7	BURST LIMIT	Removes power from trigger relay A1K5 when energized by the burst limit circuitry (high rate firing). Deenergizes the gun motor high relay A1K8 when the gun motor has attained the proper low rate speed (low rate firing).
A1K8	GUN MOTOR HIGH	Applies power to A6A2 gun motor when energized by the action and trigger control circuits.
A1K9	TIME DELAY	Energizes gun motor low relay A1K10, thereby applying power to the gun motor during low rate firing. Also keeps A1K10 energized for a short time after trigger is released, thereby allowing the gun to clear.
A1K10	GUN MOTOR LOW	Applies 8.84 vdc to A6A2 gun motor during low rate firing.
A1K11	CLEARING	When energized, applies power to the declutching solenoid A6A3.

Figure S-39. Detailed interconnection diagram (sheet 2 of 20).

AR 905497

RELAYS AND THEIR FUNCTIONS - CONT.

RELAY		FUNCTION	RELAY		FUNCTION
A1K12	LAST ROUND (INOPERATIVE)		A21K22	ACTION SWITCH COMMAND	Activates via contacts of action relay (A1K3) whenever the mode selector switch (A2A1S1) is positioned at RADAR, MAN, or TEST. In RADAR and TEST modes, supplies 24 vdc to foot switch (A24S1); in RADAR, MAN, and TEST modes, supplies 24 vdc to SCG; and in TEST mode, supplies 24 vdc to electrical cage off relay (A21K21).
A1K13	ELEVATION LOWER LIMIT	Normally energized, it allows normal cannon movement in elevation except when the mount drives into the -5° limit switch. However, if the cannon is over an open hatch, A1K13 will prevent cannon depression below 18° .	A21K23	10-SECOND TIME DELAY	Allows 24 vdc to be applied to the external range control (A10), and 24 vdc to the reticle lamp A3DS1 ten seconds after application of system power. It also applies 19 vdc to the SCG power supply to generate the ± 15 vdc required for the SCG computing circuitry.
A1K14	ACQUISITION TIME DELAY	Energizes when the radar locks on a target then removes most of the azimuth and elevation tachometer feedback, thereby causing the mount and cannon to accumulate the lead angle at a very fast rate. Deenergizes when mount and cannon have accumulated the lead angle. The slew speed (A1K14 energized) is five times normal target tracking speed.	A21K24	SIGHT CAGE	Operates in the manual and external modes when the sight cage button is pressed. It removes magnet current to the sight and applies a current which will cage the sight.
A1K15	RIGHT LIMIT	When deenergized by cannon moving into an open hatch from the right, it stops mount movement.	A21K25	EXTERNAL MODE	When the MODE switch A2A1S1 switch is set at EXT, A21K25 is activated. When A21K25 is activated, the current supplying the M61 sight is switched from the current modules to the external range control A10.
A1K16	LEFT LIMIT	When deenergized by cannon moving into an open hatch from the left, it stops mount movement.	A21K26	MANUAL MODE	When the MODE switch A2A1S1 is set at MAN, A21K26 is activated and switches the range and range rate input signals to the manually set range in range rate signals at the control panel.
A1K17	RADAR POWER	Energized in the radar, manual (MAN) or test modes, it applies 24 vdc primary power to radar power supply (unit 5) A25.	A21K27	READY-TO-FIRE	Upon a command signal from the action switch, A21K27 is activated, which allows the ready-to-fire light A3DS2 to come on (after closure of the action switch) when the various ready-to-fire logic circuits have been completed.
A21K21	SIGHT CURRENT GENERATOR (A21) ELECTRICAL CAGE OFF	When this relay is not activated, the normally-closed position is connected such that the sight is electrically caged. When the relay is activated upon a command signal of the test mode, manual mode, or lockon signals, the relay removes electrical cage and applies a noncaging current.			

AR 905498

Figure S-39. Detailed interconnection diagram (sheet 3 of 20).

 A1 Distribution Box Test Points

The distribution box of the mount electronics has test points which monitor various signals within the unit. These various voltages are brought out to a common test jack (A1J5) readily accessible at the lower-left side of the distribution box. However, you can use cable W33 of the AN/MWM-3 Test Set as an extender cable for ease in taking the measurements. The following distribution box test point data list gives the signals measured and displays the test point symbol for the distribution box (A1).

 A1 Distribution Box Test Point Data

Pin of A1J5	Zone	Signal or Voltage Measured
A	68C	+8.84 Vdc lo gun motor voltage
B	64C	Gun motor voltage A6A2: +24 Vdc in hi rate, +8.84 Vdc in lo rate
C	56H	+24 Vdc when burst limit relay A1K7 energized
D	52D	+24 Vdc fire pulse when action switch and trigger on control panel pressed (trigger signal to arm-safe switch or arming connector)
E	58D	+24 Vdc fire pulse to trigger relay A1K5 through arm-safe switch or arming connector
F	56J	+24 Vdc until burst limit circuit times down selected by BURST LIMIT switch on control panel (energizing voltage for burst LIMIT relay K7)
G	63D	(Not Used - Formerly 24 VDC to A1K12)
H	57D	+24 Vdc to release gun brake solenoid
J	56D	+24 Vdc to cut off ammo flow when clearing gun (clearing solenoid power)
K	84E	Lower limit of hatch protection reached (energizing voltage for lower limit relay K13)
L	101E	Right limit of hatch protection reached (energizing voltage for right limit relay K15)
M	86E	Left limit of hatch protection reached (energizing voltage for left limit relay K16)
N	67C	+8.84 lo gun motor voltage
P	53B	+24 Vdc when radar power relay A1K17 energized (system power to radar)
R	69B	Across plus side of VOLTS meter A1M2 (external power)
S	68J	+330 Vdc to firing contact when A1K6 energized (gun firing voltage)
T	81F	+24 Vdc for turret power enable relay A1K4
U	50B	115 Vac 400 Hz phase B from inverter A5
V	50B	115 Vac 400 Hz phase A from inverter A5
W	50B	115 Vac 400 Hz phase C from inverter A5
X	66C	+24 Vdc loading command input signal to A1K1

 A1 Distribution Box Test Point Data - Continued

Pin of A1J5	Zone	Signal or Voltage Measured
Y	50E	+24 Vdc system power through A1CB2
Z	68C	+24 Vdc gun motor voltage
a	85F	Acquisition time delay relay enable voltage for A1K14
b	50G	+24 Vdc auto gun clear pulse through action relay A1K3
c	52B	115 Vac 400 Hz single phase from inverter
d	52C	115 Vac 400 Hz single phase return
e	69B	Ground
f	58H	(Not Used - Formerly 24 VDC to A1K12)
g	68F	+24 Vdc to clearing time delay circuits
h	65B	+24 Vdc pulse to hi gun motor A1K8, pulse duration depends on burst limit selected
i	66B	+24 Vdc while loading relay A1K1 energized (loading motor power)
j	64C	+24 Vdc to low gun motor relay A1K10
k	51E	+24 Vdc system power input from control panel to A1K2
m	55C	+330 Vdc firing voltage from converter A1A3
n	58F	+24 Vdc while clearing relay A1K11 not energized
p	54E	+24 Vdc to energize firing volts relay A1K6 time delay (+24 Vdc = relay K6 deenergized)
q	57G	+24 Vdc until lo time delay expires to permit gun to accelerate rapidly at first
r	58H	Not Used
s	58G	+24 Vdc to trigger relay A1K5: pulse with A1K7 energized in hi rate constant in lo rate as long as trigger held
t	56G	+24 Vdc starts lo time delay circuit for energizing time delay relay A1K9 High gun motor relay K8 energized before burst limit)

Figure S-59. Detailed interconnection diagram (sheet 5 of 20).

AR907951

A2 CONTROL PANEL
COMPONENT REFERENCE LIST

A2 CONTROL PANEL INDICATORS		ZONE
A2A1DS1	SYSTEM POWER	130F
A2A1DS2	GUN POWER	130F
A2A1DS3	GOOD WHEN LIT	126F
A2A1DS4	READY WHEN LIT	126G
A2A1DS5	LOW VOLTAGE WARNING	131G

A2 CONTROL PANEL SWITCHES		ZONE
A2A1S1	MODE SELECTOR SWITCH DECK A DECK B DECK C	127, 128D 129-131D 137-139C
A2A1S2	GUN POWER SWITCH	136E
A2A1S3	GUN CLEAR SWITCH	140C
A2A1S4	FIRING RATE BURST LIMIT SWITCH	140-143H
A2A1S5	SYSTEM POWER SWITCH	130E
A2A1S6	RIGHT LIMIT SWITCH	138D
A2A1S7	LEFT LIMIT SWITCH	138D
A2A1S8	LOW VOLTAGE TEST/ OVERRIDE SWITCH	132H
A2A3S1 AND A2A4S1	ACTION SWITCHES	128E
A2A3S2 AND A2A4S2	SIGHT CAGE BUTTON TRIGGER SWITCH	128F 127E 129H

A2 CONTROL PANEL		ZONE
A2A1G1	AZ AIDED LAYING TACH	143B
A2A1M1	ROUNDS COUNTER	141B
A2A1R1	SIGHT LAMP (M61) POT	130B
A2A1R2	FIXED RESISTOR	129B
A2A1R3	RANGE POT	126E
A2A1R4	TARGET SPEED POT	126F
A2A1R5	100 ROUND BURST POT	140H
A2A1R6	60 ROUND BURST POT	140G
A2A1R7	30 ROUND BURST POT	140G
A2A1R8	10 ROUND BURST POT	141G
A2A1R9	LO RATE POT	142G
A2A1R10	AZ HAND CONTROL POT	140D
A2A2G1	EL AIDED LAYING TACH	130H
A2A2R1	EL HAND CONTROL POT	136G

A2 Control Panel Test Points

Test points on the control panel permit you to monitor various input and output signals of the control panel. These signals are brought out to a common test jack (A2J5) for measurement. This test jack is located at the bottom right front, next to A2J2. For ease in making the specified measurements, you can use cable W31 of the AN/MWM-3 Test Set as an extender cable. The following control panel test point data list gives the signals measured and displays the test point symbol for the control panel (A2).

A2 Control Panel Test Point Data

Pin of A2J5	Zone	Signal or Voltage Measured
A	130B	+24 Vdc for sight reticle brightness circuit
B	129C	Manual mode selected for sight current generator
C	129D	+24 Vdc system power input to switch
D	137F	Elevation control
E	126K	External mode ready to fire command input to sight current generator
F	138G	Elevation control
G	125D	Sight cage command from hand grip
H	137F	Elevation control
J	125K	External mode range estimate input to sight current generator
K	142D	Azimuth control
L	128H	115 Vac 400 Hz single phase return from inverter via distribution box
M	139D	Azimuth control
N	128H	115 Vac 400 Hz single phase from inverter via distribution box
P	139D	Azimuth control
R	142B	Rounds remaining decrement voltage pulse
S	126C	+24 Vdc to 10-second delay circuit in sight current generator
T	128B	+24 Vdc to energize radar power in distribution box
U	128G	+24 Vdc when action switches closed to sight current generator
V	130K	+24 Vdc trigger voltage to firing circuit
W	130K	+24 Vdc trigger voltage in from distribution box
X	137D	System power input to control panel
Y	125E	Manual range voltage to sight current generator
Z	126F	Manual target speed voltage to sight current generator
a	126K	Cannon elevation less than 80° for ready-to-fire circuit
b	140J	Firing rate burst limiting output to distribution box
c	138J	Firing rate burst limit circuit input voltage

AR 907952

Figure S-39. Detailed interconnection diagram (sheet 6 of 20).


A1 DISTRIBUTION BOX
COMPONENT REFERENCE LIST

A1 DISTRIBUTION BOX		ZONE
K1	LOADING	67B
K2	SYSTEM POWER	51, 52E
K3	ACTION	53G-J
K4	TURRET POWER	81D, E
K5	TRIGGER	54G
K6	FIRING VOLTS	54C
K7	BURST LIMIT	55G-J
K8	GUN MOTOR HIGH	65B
K9	TIME DELAY	56F
K10	GUN MOTOR LOW	64B
K11	CLEARING	58F
K12	LAST ROUND (INOPERATIVE)	58G, H
K13	ELEVATION LOWER LIMIT	83, 84E
K14	ACQUISITION TIME DELAY	85E
K15	RIGHT LIMIT	82G
K16	LEFT LIMIT	84, 85G
K17	RADAR POWER	53B

A1 DISTRIBUTION BOX COMPONENTS		ZONE
A3	CONVERTER	56B
A4	FILTER	50F, G
C1		62B
C2		55B
C3		81D
CB1	SCG POWER	51F
CB2	SYSTEM POWER	53E
CB3	INVERTER POWER	51E
CB4	SIGHT GYRO POWER	51B
CB6		82D
CB7		82D
CB8		82D
CR1		69D
CR2		69C
CR3		67C
CR4		57B
CR5		56B
CR6		66B
M1	AMPS	69C
M2	VOLTS	69C
M3	ELAPSED TIME INDICATOR	50F
R1	SHUNT	70C
R2		63B
R3		55C
R4		55B
S1	NORM-STATIC-TEST SWITCH	82D, E

AR 905499

Figure S-39. Detailed interconnection diagram (sheet 4 of 20).



A21 Sight Current Generator Test Points

The sight current generator is provided with test points that monitor the various signals in the unit. These signals are brought out to a common test jack (A21J7) readily accessible on the side of the unit. However, you may use cable W32 of the AN/MWM 3 (OMTS) as an extender cable for ease in taking the measurements. The following sight current generator test point data list gives the signals measured and displays the test point symbol for the sight current generator (A21).

AMC84-1083

Figure S-39. Detailed interconnection diagram (sheet 7 of 20).

○ A21 Sight Current Generator Test Point Data - Cont.

Pin of A21J7	Zone	Signal or Voltage Measured
f	Fig S-15	Range is less than 2200 meters signal for ready-to-fire = +15 Vdc
g	Fig S-10	Sight magnet current module VI_M input (0 to +13 Vdc)
h	Fig S-12	Sight torque current module VI_T input (-13 to +13 Vdc)
i	Fig S-10	Range air density reference voltage (-3.4 Vdc)
j	Fig S-10	Muzzle velocity (MV) magnet current fifth term
k	Fig S-10	Muzzle velocity (MV) magnet current fifth term
m	Fig S-10	+1/RN magnet current first term
n	Fig S-10	$-\lambda^2/R$ magnet current fourth term
p	Fig S-12	Super elevation (SUPER EL) torque current third term
q	Fig S-10	Divider reference
r	Fig S-10	Buffered range reference (+R')
s	Fig S-10	$+R/R^2$ magnet current third term
u	Fig S-10	$-R/R$ magnet current second term
v	41C	Test mode low calibration signal (GO = 15Vdc, NOGO = 0)
w	41C	Test mode high calibration signal (GO = 15Vdc, NOGO = 0)
x	10G, S-10	Range signal from radar (Range input to sight current generator)
y	Fig S-14 Fig S-15	Range signal (buffered) 0.834 (Range input)
z	28G	+24 Vdc acquisition time delay pulse from A1K14
AA	10F S-10	Range rate signal from radar (Range rate input signal to sight current generator)
BB	20E, Fig S-12	$+KI_M^2$ signal to the λ^3 pot
CC	Fig S-15	Acquisition time delay signal
DD	Fig S-19	Sight magnet current feedback fl_M (buffered)

Pin of A21J7	Zone	Signal or Voltage Measured
EE	Fig S-12	$-KI_M^2\lambda^2$ signal (input to amplifier for λ_E pot excitation)
FF	Fig S-10 Fig S-15	λ^2 signal from antenna
GG	Fig S-12	26 V P-P serrasoid (AC)
HH	32F	Sight cage command from hand grip (+24 Vdc when sight caged)

Figure S-39. Detailed interconnection diagram (sheet 8 of 20).

AR907955




Figure S-39. Detailed interconnection diagram (sheet 9 of 20).

AR 905086




Figure S-39. Detailed interconnection diagram (sheet 11 of 20).

AR 905087






Figure S-39. Detailed interconnection diagram (sheet 13 of 20).

AMC84-1120

Change 2

1-91/(1-92 blank)








Figure 3-39. Detailed interconnection diagram (sheet 15 of 20).

Change 2

1-95/(1-96 blank)




AR 905092



NOTE
ALSO REFER TO FIGURE S-64 WHICH
COVERS THE INTERFACE WIRING DIAGRAM
FOR THE M157E1 MOUNT AND M741 CHASSIS.

Figure S-39. Detailed interconnection diagram (sheet 1 of 2).



AMC84-1121




Figure S-39. Detailed interconnection diagram (sheet 19 of 20).

AMC84-1122




Figure S-39. Detailed interconnection diagram (sheet 20 of 20).

AMC84-1123





Figure S-40. Cable assembly W1 wiring diagram. ■



Figure S-41. Cable assembly W2 wiring diagram. ■







Figure S-42. Cable assembly W3 wiring diagram. ■





Figure S-43. Cable assembly W4 wiring diagram. ■





Figure S-44. Cable assembly W5 wiring diagram. ■




Figure S-45. Cable assembly W6 wiring diagram. ■





Figure S-46. Cable assembly W7 wiring diagram. ■






Figure S-47. Cable assembly W8 wiring diagram. ■






Figure S-50. Cable assembly W11 wiring diagram. ■




Figure S-52. Cable assembly W13 wiring diagram. ■







Figure S-51. Cable assembly W12 wiring diagram. ■







Figure S-53 Cable assembly W14 wiring diagram








Figure S-54 Cable assembly W17 wiring diagram

CABLE SUB NO	WIRE NO	FROM	EQUIP WITH PART NO	FIG	NOTE	PART NO	AWG	COLOR (NOTE 7)	TO	EQUIP WITH PART NO	FIG	NOTE
13	1	P1-A					20	BLU	P2-A			
	2	P1-B					20	WHT	P2-B			
	SHLD	P1-Z	11829974-1	A					P2-Z	11829974-1	A	
1	1	P1-G					20	WHT	P2-G			
	2	P1-H					20	WHT	P2-H			
	1	P1-K					20	BLU	P2-K			
14	2	P1-L					20	WHT	P2-L			
	SHLD	P1-e	11829974-1	A					P2-e	11829974-1	A	
	1	P1-M					20	BLU	P2-M			
15	2	P1-N					20	WHT	P2-N			
	SHLD	P1-I	11829974-1	A					P2-I	11829974-1	A	
	3	P1-U					20	WHT	P2-U			
9	1	P1-V					20	WHT	P2-V			
	10	P1-W					20	WHT	P2-W			
	1	P1-X					20	BLU	P2-X			
16	2	P1-Y					20	WHT	P2-Y			
	SHLD	P1-k	11829974-1	A					P2-k	11829974-1	A	
	1	P1-a					16	BLU	P2-a			
18	2	P1-m					16	WHT	P2-m			
	SHLD	P1-b	11829974-1	A					P2-b	11829974-1	A	
	4	P1-c					16	WHT	P2-c			
11	1	P1-d					20	WHT	P2-d			
	1	P1-g					16	BLU	P2-g			
	2	P1-q					16	WHT	P2-q			
19	SHLD	P1-h	11829974-1	A					P2-h	11829974-1	A	
	1	P1+					20	BLU	P2+			
	2	P1-s					20	WHT	P2-s			
17	SHLD	P1-j	11829974-1	A					P2-j	11829974-1	A	
	3	P1-n					16	WHT	P2-n			
	6	P1-p					16	WHT	P2-p			
7	1	P1-r					16	WHT	P2-r			
	5	P1-t					16	WHT	P2-t			
	12	P1-j					20	WHT	P2-j			
—	SHLD	P1-C	M81044/12-20-9	B					P2-C	M81044/12-20-9	B	


Figure S-55 Cable assembly W101 wiring diagram




CABLE SUB NO	WIRE NO	FROM	EQUIP WITH PART NO	FIG	NOTE	PART NO	AWG	COLOR (NOTE 7)	TO	EQUIP WITH PART NO	FIG	NOTE
10	1	P1-B					20	BLU	P2-B			
	2	P1-C					20	WHT	P2-C			
	SHLD	P1-D	11829974-1	A					P2-D	11829974-1	A	
1	2	P1-E					12	WHT	P2-E			
	1	P1-W					12	WHT	P2-W			
	4	P1-F					20	BLU	P2-F			
11	1	P1-G					20	BLU	P2-G			
	2	P1-H					20	WHT	P2-H			
	SHLD	P1-J	11829974-1	A					P2-J	11829974-1	A	
3	1	P1-K					20	BLU	P2-K			
	2	P1-M					20	WHT	P2-M			
	3	P1-N					20	WHT	P2-N			
2	1	P1-R					20	WHT	P2-R			
	SHLD	P1-P	11829974-1	A					P2-P	11829974-1	A	
	9	2	P1-Y				12	WHT	P2-Y			
5	1	P1-X					12	BLU	P2-X			
	1	P1-e					20	WHT	P2-e			
	12	P1-U					20	WHT	P2-U			
6	SHLD	P1-T	11829974-1	A					P2-T	11829974-1	A	
	1	P1-Z					20	WHT	P2-Z			
	7	P1-a					20	WHT	P2-a			
8	1	P1-b					20	WHT	P2-b			
	SHLD	P1-A	M81044/12-20-9	B					P2-A	M81044/12-20-9	B	

Figure S-56 Cable assembly W102 wiring diagram


CABLE	WIRE NO	FROM	EQUIP WITH PART NO	FIG	NOTE	CABLE PART NO	AWG	COLOR (NOTE 1)	TO	EQUIP WITH PART NO	FIG	NOTE
W3	1	P1-HH	SEE FIG	—	—	M81044/12-20-9	20	WHITE	P2-J	SEE FIG	—	—
W4	1	P1-h	—	—	—	M81044/12-20-9	20	WHITE	P2-H	—	—	—
W6	1	P1-e	—	—	—	M27500-20ML2T08	20	BLUE	P2-C	—	—	—
	2	P1-f	—	—	—		20	WHITE	P2-D	—	—	—
W8	1	P1-g	—	—	—	M27500-20ML1T08	—	—	P2-G	—	—	—
	2	P1-j	—	—	—		20	WHITE	P2-A	—	—	—
W19	1	P1-z	—	—	—	M27500-20ML3T08	20	BLUE	P2-E	—	—	—
	2	P1-y	—	—	—		20	WHITE	P2-F	—	—	—
	3	P1-FF	—	—	—		20	ORANGE	P2-M	—	—	—
	SHLD	P1-GG	—	—	—		—	—	P2-L	—	—	—
SHLD	—	—	—	—	—	M81044/12-20-9	20	WHITE	P2-B	—	—	—
W1	1	P1-DD	—	—	—	M81044/12-20-9	20	WHITE	P3-U	—	—	—
W2	1	P1-R	—	—	—	M81044/12-20-9	20	WHITE	P3-R	—	—	—
W5	1	P1-H	—	—	—	M27500-20ML3T08	20	BLUE	P3-L	—	—	—
	2	P1-J	—	—	—		20	WHITE	P3-P	—	—	—
	3	P1-K	—	—	—		20	ORANGE	P3-N	—	—	—
	SHLD	P1-M	—	—	—		—	—	P3-M	—	—	—
W7	1	P1-AA	—	—	—	M27500-20ML1T08	20	WHITE	P3-T	—	—	—
W9	1	P1-B	—	—	—	M27500-20ML2T08	20	BLUE	P3-e	—	—	—
	2	P1-C	—	—	—		20	WHITE	P3-g	—	—	—
W10	1	P1-X	—	—	—		—	—	P3-J	—	—	—
	2	P1-N	—	—	—		20	BLUE	P3-K	—	—	—
W11	1	P1-P	—	—	—		20	WHITE	P3-G	—	—	—
	2	P1-U	—	—	—		20	WHITE	P3-H	—	—	—
W12	1	P1-p	—	—	—		20	BLUE	P3-E	—	—	—
	2	P1-m	—	—	—		20	WHITE	P3-F	—	—	—
W13	1	P1-S	—	—	—		20	—	P3-X	—	—	—
	2	P1-y	—	—	—		20	BLUE	P3-Y	—	—	—
W14	1	P1-EE	—	—	—		20	WHITE	P3-Z	—	—	—
	2	P1-EE	—	—	—		20	BLUE	P3-a	—	—	—
W15	1	P1-c	—	—	—	M27500-20ML2T08	20	WHITE	P3-b	—	—	—
	2	P1-v	—	—	—		20	BLUE	P3-d	—	—	—
W16	1	P1-A	—	—	—	M27500-20ML3T08	20	WHITE	P3-f	—	—	—
	2	P1-W	—	—	—		20	BLUE	P3-C	—	—	—
W17	1	P1-D	—	—	—	M27500-20ML3T08	20	WHITE	P3-D	—	—	—
	2	P1-E	—	—	—		20	ORANGE	P3-W	—	—	—
W18	1	P1-Z	—	—	—	M27500-20ML3T08	20	BLUE	P3-V	—	—	—
	2	P1-a	—	—	—		20	WHITE	P3-B	—	—	—
SHLD	1	P1-q	—	—	—	M81044/12-20-9	20	ORANGE	P3-A	—	—	—
	2	P1-r	—	—	—		20	BLUE	P3-h	—	—	—
SHLD	1	P1-CC	—	—	—		20	WHITE	P3-l	—	—	—
	2	P1-s	—	—	—		20	ORANGE	P3-g	—	—	—
SHLD	—	—	SEE FIG	J	—		—	—	P3-S	SEE FIG	J	—




W103 P1 PIN




W103 P2 SOCKET



W103 P3 SOCKET




W104 P1 PIN




W104 P2 SOCKET

CABLE SUB NO	WIRE NO	FROM	EQUIP WITH PART NO	FIG	NOTE	PART NO	AWG	COLOR (NOTE 1)	TO	EQUIP WITH PART NO	FIG	NOTE
1	1	P1-A	—	—	—	11829974-1	20	BLU	P2-A	—	—	—
	2	P1-B	—	—	—		20	WHT	P2-B	—	—	—
3	1	P1-J	—	—	—	11829984-1	20	—	P2-M	—	—	—
	2	P1-K	—	—	—		20	—	P2-G	—	—	—
2	1	P1-F	—	—	—	11829991 (W1)	20	WHT	P2-F	—	—	—
	2	P1-G	—	—	—		20	BLU	P2-P	—	—	—
—	1	P1-H	—	—	—	11829974-1	20	ORN	P2-E	—	—	—
	2	P1-I	—	—	—		20	—	P2-N	—	—	—
SHLD	—	P1-D	M81044/12-20-9	B	—		20	WHT	P2-C	M81044/12-20-9	B	—


Figure S-58 Cable assembly W104 wiring diagram




W105 P2 PIN




W105 P4 PIN



W105 P1 PIN



W105 P3 PIN





W105 P5 PIN

CABLE	WIRE NO	FROM	EQUIP WITH PART NO	FIG	NOTE	CABLE PART NO	AWG	COLOR	TO	EQUIP WITH PART NO	FIG	NOTE
W1	1	P1-E	SEE FIG	L	—	11829996 (W1)	24	—	P2-E	SEE FIG	M	—
	2	P1-B	—	—	—		24	—	P2-B	—	—	—
	3	P1-C	—	—	—		24	—	P2-C	—	—	—
	4	P1-D	—	—	—		24	—	P2-D	—	—	—
W2	1	P1-E	—	—	—	11829997 (W2)	22	—	P2-E	—	—	—
	2	P1-G	—	—	—		22	—	P2-G	—	—	—
W3	1	P1-A	—	—	—	11829993 (W3)	19	—	P2-A	—	—	—
	SHLD	—	—	—	—		—	—	P2-A	—	—	—
W4	1	P4-B	—	—	—	M1788810058 (W4)	21	—	P3-B	—	—	—
W5	1	P4-F	—	—	—	10549139(W5)	24	—	P3-F	—	—	—
W6	1	P4-G	—	—	—	10549114(W6)	22	—	P3-G	—	—	—
SHLD	1	P4-E	—	—	—		—	—	—	—	—	—
	2	P4-A	—	—	—		—	—	—	—	—	—
—	1	P4-C	—	—	—		—	—	—	—	—	—
	2	P4-D	—	—	—		—	—	—	—	—	—
W7	1	P5	—	—	—	11829993(W7)	19	—	P3-A	—	—	—
SHLD	—	—	—	—	—		—	—	P3-C	SEE FIG	V	—



Figure S-59 Cable assembly W105 wiring diagram

Figure S-57 Cable assembly W103 wiring diagram





CABLE SUB NO	WIRE NO	FROM	EQUIP WITH PART NO	FIG	NOTE	PART NO	AWG	COLOR	TO	EQUIP WITH PART NO	FIG	NOTE
1	1	P1-D	11830001-2	E		11829992 (W1)	22	WHT	P2-D	11830001-2	E	
	SHLD	P1-C	11830001-1	E	7		22	WHT	P2-C	11830001-1	E	7
2	1	P1-E	11830001-2	E		11830001-1	22	WHT	P2-E	11830001-2	E	
	SHLD	P1-F	11830001-1	E	7		22	WHT	P2-F	11830001-1	E	7
—	—	P1-G	11830001-1	B		—	—	—	P2-G	11830001-1	B	
—	—	P1-A	11830001-2	8		—	—	—	P2-A	11830001-2	8	
—	—	P1-B	11830001-2	8		—	—	—	P2-B	11830001-2	8	

Figure S-60. Cable assembly W106 wiring diagram. ■



CABLE SUB NO	WIRE NO	FROM	EQUIP WITH PART NO	FIG	NOTE	PART NO	AWG	COLOR	TO	EQUIP WITH PART NO	FIG	NOTE
7	1	P1-G				11829974-1	20	BLU	P2-G			
	2	P1-H					20	WHT	P2-H			
	3	P1-c					20	ORN	P2-c			
	SHLD	P1-b	11829974-1	A					P2-b	11829974-1	A	
9	1	P1-S				11829974-1	20	BLU	P2-S			
	2	P1-g					20	WHT	P2-g			
	3	P1-h					20	ORN	P2-h			
	4	P1-i					20	GRN	P2-i			
3	1	P1-W				11829994 (W1)	20	BLU	P2-W			
	2	P1-X					20	WHT	P2-X			
	SHLD	P1-j	11829974-1	A					P2-j	11829974-1	A	
2		P1-Y					20	WHT	P2-Y			
4		P1-a					20	WHT	P2-a			
6		P1-n					20	WHT	P2-n			
5	1	P1-d				11829974-1	20	BLU	P2-d			
	2	P1-e					20	WHT	P2-e			
	SHLD	P1-p	11829974-1	A					P2-p	11829974-1	A	
1	1	P1-m				11829974-1	16	BLU	P2-m			
	2	P1-r					16	WHT	P2-r			
	SHLD	P1-k	11829974-1	A					P2-k	11829974-1	A	
8		P1-q					20	WHT	P2-q			
—	SHLD	P1-A	M81044/12-20-9	B			20	WHT	P2-A	M81044/12-20-9	B	

Figure S-61. Cable assembly W107 wiring diagram. ■



CABLE SUB NO	WIRE NO	FROM	EQUIP WITH PART NO	FIG	NOTE	PART NO	AWG	COLOR	TO	EQUIP WITH PART NO	FIG	NOTE
1	1	P1-D				11829974-1	20	BLU	P2-D			
	2	P1-E					20	WHT	P2-E			
	3	P1-F					20	ORN	P2-F			
	SHLD	P1-Z	11829974-1	A					P2-Z	11829974-1	A	
9	1	P1-G				11829974-1	20	BLU	P2-G			
	2	P1-H					20	WHT	P2-H			
	3	P1-c					20	ORN	P2-c			
	SHLD	P1-b	11829974-1	A					P2-b	11829974-1	A	
11	1	P1-M				11829974-1	20	BLU	P2-M			
	2	P1-N					20	WHT	P2-N			
	3	P1-P					20	ORN	P2-P			
	SHLD	P1-R	11829974-1	A					P2-R	11829974-1	A	
2	1	P1-S				11829995 (W1)	20	BLU	P2-S			
	2	P1-f					20	WHT	P2-f			
	3	P1-g					20	ORN	P2-g			
	4	P1-h					20	GRN	P2-h			
3	1	P1-W				11829974-1	20	BLU	P2-W			
	2	P1-X					20	WHT	P2-X			
	SHLD	P1-j	11829974-1	A					P2-j	11829974-1	A	
4		P1-Y					20	WHT	P2-Y			
6		P1-a					20	WHT	P2-a			
5	1	P1-d				11829974-1	20	BLU	P2-d			
	2	P1-e					20	WHT	P2-e			
	SHLD	P1-p	11829974-1	A					P2-p	11829974-1	A	
8		P1-q					20	WHT	P2-q			
10		P1-n					20	WHT	P2-n			
7	1	P1-r				11829974-1	16	BLU	P2-r			
	2	P1-m					16	WHT	P2-m			
	SHLD	P1-k	11829974-1	A					P2-k	11829974-1	A	
—		P1-A	M81044/12-20-9				20	WHT	P2-A	M81044/12-20-9		

Figure S-62. Cable assembly W108 wiring diagram. ■

M163A1 CABLES

CABLE	ROUTING SHOWN ON			
	SH. 2	SH. 3	SH. 4	SH. 5
W1			X	
W2			X	
W3				X
W4			X	
W5		X		
W6		X		X
W7		X		
W8				X
W9				X
W10				X
W11	X			
W12		X		
W13			X	
W14	X			
W15	X			
W16	X			
W17				X
A24JP1				X
W101		X		
W102		X		
W103		X		
W104		X		
W105		X		
W106		X		
W107		X		
W108		X		

AR 905119

Figure S-63. Cable routing (sheet 1 of 5).




Figure S-63. Cable routing (sheet 2 of 5).




Figure S-63. Cable routing (sheet 3 of 5).

AR 908112




Figure S-63. Cable routing (sheet 4 of 5).

AMC84-1219




Figure S-63. Cable routing (sheet 5 of 5).




Figure S-64. Interface wiring diagram, M157A1 mount and M741 chassis. ■




Figure S-65. Slip ring assembly wiring diagram.




Figure S-66. Radar set AN/VPS-2 simplified functional schematic (sheet 1 of 4)

AMC84-1091




Figure S-66. Radar set AN/VPS-2 simplified functional schematic (sheet 2 of 4).

AMC84 1092




Figure S-66. Radar set AN/VPS-2 simplified functional schematic (sheet 3 of 4).




Figure S-66. Radar set AN/VPS-2 simplified functional schematic (sheet 4 of 4).

AR 905128




Figure S-67. Radar 6.5-volt and 5-volt power distribution functional schematic diagram (sheet 1 of 2)




Figure S-67. Radar 6.5-volt and 5-volt power distribution functional schematic diagram (sheet 2 of 2).

AMC84-1093





Figure S-68. Radar 23-volt and 15-volt power distribution functional schematic diagram (sheet 1 of 2).

AR 905131



AMC84 1095
Figure 8-69. Radar 24-volt power distribution functional schematic diagram (sheet 1 of 2)





Figure S-69. Radar 24-volt power distribution functional schematic diagram (sheet 2 of 2).




- NOTES
1. REFER TO +24-VOLT POWER DISTRIBUTION FUNCTIONAL SCHEMATIC DIAGRAM.
 2. REFER TO TRANSMITTING SYSTEM FUNCTIONAL SCHEMATIC DIAGRAM.
 3. REFER TO RECEIVING SYSTEM FUNCTIONAL SYSTEM DIAGRAM.

Figure S-70. Radar 28-volt power distribution functional schematic diagram (sheet 1 of 2)

AMC84 1096

Change 2 1-149/(1-150 blank)






Figure S-71. Radar 33-volt and 25-volt power distribution functional schematic diagram (sheet 1 of 2).






Figure S-71. Radar 33-volt and 25-volt power distribution functional schematic diagram (sheet 2 of 2).

AR 905138



AR 905138

Figure S-71. Radar 33-volt and 25-volt power distribution functional schematic diagram (sheet 2 of 2).






Figure S-72. Radar antenna positioning system functional schematic diagram (sheet 2 of 2).




Figure S-73. Radar synchronizing system functional schematic diagram (sheet 1 of 2).







Figure S-73. Radar synchronizing system functional schematic diagram (sheet 2 of 2).

AMC84-1099







AMC84-1216 ■

Figure S-75. RF system functional schematic diagram (sheet 1 of 2).

Change 2

1-167/(1-168 blank)




Figure S-75. RF system functional schematic diagram (sheet 2 of 2).

RECEIVED RF




Figure S-76. Radar receiving system functional schematic diagram (sheet 1 of 4).

RECEIVED RF






Figure S-76. Radar receiving system functional schematic diagram (Sheet 1 of 4).



AR 905148

Figure S-76. Radar receiving system functional schematic diagram (sheet 2 of 4).



AMC84 1102

Figure 5-76. Radar receiving system functional schematic diagram (Sheet 1 of 4).

Change 2

1 175/(1 176 blank)




Figure S-76. Radar receiving system functional schematic diagram (sheet 4 of 4).





Figure S-76. Radar receiving system functional schematic diagram (sheet 4 of 4).




- NOTES
1. ALL COMPONENTS LOCATED IN RANGE COMPUTER UNIT 4 UNLESS OTHERWISE SPECIFIED
 2. MIDRANGE CALIBRATION INDICATOR LAMP 4DS1 BLINKS AT 1 CPS RATE DURING SEARCH MODE. IN TRACK MODE, 4DS1 ILLUMINATES WHEN TARGET RANGE IS BETWEEN 2400 METERS AND 2560 METERS.
 3. REFER TO RECEIVING SYSTEM FUNCTIONAL SCHEMATIC DIAGRAM
 4. REFER TO SYNCHRONIZING SYSTEM FUNCTIONAL SCHEMATIC DIAGRAM
 5. REFER TO +15 VOLT POWER DISTRIBUTION FUNCTIONAL SCHEMATIC DIAGRAM
 6. REFER TO +5 VOLT POWER DISTRIBUTION FUNCTIONAL SCHEMATIC DIAGRAM

REFERENCE DESIGNATION	ZONE
4C5	A 4
4C6	A 4
4C7	C 5
4C9	C 2 D 2
4CR4	C 5
4K3	B 5 C 5
4R2	D 2
4R3	C 2 D 2
4S2	C 5 D 5
4S3	D 5
4S4	C 5
4S5	D 6
4TPC	C 5
4TP7	D 5
4TP8	B 2
4TP26	D 6
4TP46	D 2
4TP47	C 2
4TP48	D 1
4TP49	D 1
4A21R13	A 3
4A21TP1	A 2
4A21TP2	A 3
4A21TP3	A 2
4A21TP4	A 3

AMC84-1103

Figure S-77. Radar ranging system functional schematic diagram (sheet 1 of 6).






Figure S-77. Radar ranging system functional schematic diagram (sheet 3 of 6).

AR 905153




Figure S-77. Radar ranging system functional schematic diagram (sheet 4 of 6).

AR 905154





Figure S-77. Radar ranging system functional schematic diagram (sheet 5 of 6).

AMC84-1105

AMC84-1106 ■

NOTES:

1. UNLESS OTHERWISE SPECIFIED RESISTANCE IS IN OHMS, CAPACITANCE IS IN MICROFARADS.
2. ALL DIODES IN4003 UNLESS OTHERWISE SPECIFIED.
3. K12 FUNCTIONS ARE NOT UTILIZED IN THIS APPLICATION.
4. POLARITY DATA AND CONVENTIONS.
A: MOTORS ARE VIEWED FROM THE BRAKE END.
B: POT AND TACH ARE VIEWED FROM SHAFT END.
C: ON AMPLIFIERS
POSITIVE APPLIED TO PIN G GIVES OUTPUT ON PIN L.
D: TACH POLARITY AS MARKED WHEN DRIVEN CCW.
E: CW POT ROTATION GROUND NO. 1 TERMINAL.
F: CW AND CCW REFER TO POT, TACH, AND MOTORS.
G: RIGHT LEFT, UP AND DOWN REFER TO GUN.
5. ALL MOMENTARY SWITCHES ARE SHOWN IN THE UNACTUATED STATE UNLESS OTHERWISE SPECIFIED.
6. THIS IS A NORMALLY OPEN SWITCH WHICH IS ACTUATED DURING INSTALLATION AND RELEASED WHEN THE DRUM IS FULL.
7. ALL RELAY CONTACTS ARE SHOWN WITH THE COIL DE-ENERGIZED.
8. THE FOLLOWING SYMBOLS AND THE APPLICABLE PIN LETTER IS USED TO DEFINE TEST POINTS.
 CONTROL PANEL
 DISTRIBUTION BOX
 SIGHT CURRENT GENERATOR
9. TAP IS MOVED TO 10.1 VOLTS AT OR BELOW 32° F.
10. FIVE POSITION ROTARY SWITCH WITH HI RATE CONTACTS CLOSED IN ALL HI RATE BURST LIMIT POSITIONS.
11. POSITIVE LEAD ANGLE WHEN GUN IS ABOVE LINE OF SIGHT FOR INCOMING TARGETS.
12. LIGHT BLINKS WHEN SYSTEM VOLTAGE DROPS BELOW 22 VDC AND REMAINS ON WHEN SYSTEM VOLTAGE DROPS BELOW 20.5 VDC AND K2 DE-ENERGIZES PLACING SYSTEM INTO GROUND MODE.




RELAY LIST


- K1 - LOADING
- K2 - SYSTEM POWER
- K3 - ACTION
- K4 - TURRET POWER
- K5 - TRIGGER
- K6 - FIRING VOLTS
- K7 - BURST LIMIT
- K8 - HI GUN MOTOR
- K9 - LO TIME DELAY
- K10 - LO GUN MOTOR
- K11 - CLEARING
- K12 - SEE NOTE 3
- K13 - LOWER LIMIT
- K14 - ACQ TIME DELAY
- K15 - RIGHT LIMIT
- K16 - LEFT LIMIT
- K17 - RADAR POWER
- K21 - ELEC CAGE OFF
- K22 - ACTION SW COMM
- K23 - 10 SEC TIME DELAY
- K24 - SIGHT CAGE
- K25 - EXTERNAL MODE
- K26 - MANUAL MODE
- K27 - READY TO FIRE

AMC84-1127

Figure S-78. M163A1 system electrical schematic diagram (sheet 1 of 5).



Change 2 **1-193/(1-194 blank)**






Figure S-78. M163A1 system electrical schematic diagram (sheet 4 of 5).

AMC84-1129






Figure S-78. M163A1 system electrical schematic diagram (sheet 5 of 5).







By Order of the Secretary of the Army:

Official:

PAUL T. SMITH
Major General, United States Army
The Adjutant General

BERNARD W. ROGERS
General, United States Army
Chief of Staff

DISTRIBUTION:

To be distributed in accordance with DA form 12-37 (qty rqr block no. 857) Organizational Maintenance requirements for for Gun, Air Defense Artillery, M163, M163A1

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL MANUALS



SOMETHING WRONG WITH THIS MANUAL?

THEN . . . JOT DOWN THE DOPE ABOUT IT ON THIS FORM, TEAR IT OUT, FOLD IT AND DROP IT IN THE MAIL!

FROM: (YOUR UNIT'S COMPLETE ADDRESS)

Your mailing address.

DATE Date you fill out this form.

PUBLICATION NUMBER

TM 9-XXXX-XXX-XX

DATE

Date of TM

TITLE

Title of TM

BE EXACT . . . PIN-POINT WHERE IT IS

IN THIS SPACE TELL WHAT IS WRONG AND WHAT SHOULD BE DONE ABOUT IT

PAGE NO.	PARA-GRAPH	FIGURE NO.	TABLE NO.
3		2	
109		51	
2-8			2-1
12	1-6a		

Item 10. Change illustration. Reason: Tube end shown assembled on wrong side of lever cam.

Item 3. The NSN and P/N are not listed on the AMDF nor the MCRL. Request correct NSN and P/N be furnished.

Preventive Maintenance Checks and Services. Item 7 under "Items to be inspected" should be changed to read as follows: Firing linkage and firing mechanism pawl.

Since there are both 20- and 30- round magazines for this rifle, data on both should be listed.

SAMPLE

TYPED NAME, GRADE OR TITLE, AND TELEPHONE NUMBER

SIGN HERE:

DA FORM 2028-2 (TEST)

P.S. . . IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR MANUAL "FIND," MAKE A CARBON COPY OF THIS AND GIVE IT TO YOUR HEADQUARTERS

AR 904501

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL MANUALS					
THEN . . . JOT DOWN THE DOPE ABOUT IT ON THIS FORM. TEAR IT OUT, FOLD IT AND DROP IT IN THE MAIL!		SOMETHING WRONG WITH THIS MANUAL?			
		FROM: (YOUR UNIT'S COMPLETE ADDRESS)			
PUBLICATION NUMBER TM9-2350-300-20-2		DATE 31 MAR 77		TITLE Gun, ADA, MI63AI	
BE EXACT . . . PIN-POINT WHERE IT IS		IN THIS SPACE TELL WHAT IS WRONG AND WHAT SHOULD BE DONE ABOUT IT.			
PAGE NO.	PARA-GRAPH	FIGURE NO.	TABLE NO.		
TYPED NAME, GRADE OR TITLE, AND TELEPHONE NUMBER				SIGN HERE	

DA FORM 2028-2 (TEST)
1 AUG 74

P.S. . . IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR MANUAL "FIND," MAKE A CARBON COPY OF THIS AND GIVE IT TO YOUR HEADQUARTERS.

AR 908236



FILL IN YOUR
UNIT'S ADDRESS

FOLD BACK

DEPARTMENT OF THE ARMY

OFFICIAL BUSINESS

Commander
US Army Armament Materiel Readiness Command
ATTN: DRSAR-MAS
Rock Island, IL 61201

FOLD BACK

TEAR ALONG DOTTED LINE

FILL IN YOUR
UNIT'S ADDRESS

FOLD BACK

DEPARTMENT OF THE ARMY

OFFICIAL BUSINESS

Commander
US Army Armament Materiel Readiness Command
ATTN: DRSAR-MAS
Rock Island, IL 61201

FOLD BACK

TEAR ALONG DOTTED LINE

REVERSE OF DA FORM 2026-2 (TEST)

AR 904803

RECOMMENDED CHANGES TO EQUIPMENT TECHNICAL MANUALS



SOMETHING WRONG WITH THIS MANUAL?

THEN . . . JOT DOWN THE
DOPE ABOUT IT ON THIS
FORM, TEAR IT OUT, FOLD
IT AND DROP IT IN THE
MAIL!

FROM: (YOUR UNIT'S COMPLETE ADDRESS)

DATE

PUBLICATION NUMBER

TM9-2350-300-20-2

DATE

31 MAR 77

TITLE

Gun, ADA, M163AI

BE EXACT . . . PIN-POINT WHERE IT IS

PAGE
NO.

PARA-
GRAPH

FIGURE
NO.

TABLE
NO.

IN THIS SPACE TELL WHAT IS WRONG
AND WHAT SHOULD BE DONE ABOUT IT:

TEAR ALONG DOTTED LINE

TYPED NAME, GRADE OR TITLE, AND TELEPHONE NUMBER

SIGN HERE:

DA FORM 1 AUG 74 2028-2 (TEST)

P.S. . . IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR MANUAL "FIND," MAKE
A CARBON COPY OF THIS AND GIVE IT TO YOUR HEADQUARTERS.

AR 908236

FILL IN YOUR
UNIT'S ADDRESS

FOLD BACK

DEPARTMENT OF THE ARMY

OFFICIAL BUSINESS

Commander
US Army Armament Materiel Readiness Command
ATTN: DRSAR-MAS
Rock Island, IL 61201

FOLD BACK

TEAR ALONG DOTTED LINE

**THEN . . . JOT DOWN THE
DOPE ABOUT IT ON THIS
FORM, TEAR IT OUT, FOLD
IT AND DROP IT IN THE
MAIL!**

FROM: (YOUR UNIT'S COMPLETE ADDRESS)

DATE

PUBLICATION NUMBER

TM9-2350-300-20-2

DATE

31 MAR 77

TITLE

Gun, ADA, MI63AI

BE EXACT . . . PIN-POINT WHERE IT IS

IN THIS SPACE TELL WHAT IS WRONG
AND WHAT SHOULD BE DONE ABOUT IT:

PAGE
NO.

**PARA-
GRAPH**

FIGURE
NO

TABLE NO.	DESCRIPTION	DATE	BY
1	...	...	...
2	...	...	...
3	...	...	...
4	...	...	...
5	...	...	...
6	...	...	...
7	...	...	...
8	...	...	...
9	...	...	...
10	...	...	...
11	...	...	...
12	...	...	...
13	...	...	...
14	...	...	...
15	...	...	...
16	...	...	...
17	...	...	...
18	...	...	...
19	...	...	...
20	...	...	...
21	...	...	...
22	...	...	...
23	...	...	...
24	...	...	...
25	...	...	...
26	...	...	...
27	...	...	...
28	...	...	...
29	...	...	...
30	...	...	...
31	...	...	...
32	...	...	...
33	...	...	...
34	...	...	...
35	...	...	...
36	...	...	...
37	...	...	...
38	...	...	...
39	...	...	...
40	...	...	...
41	...	...	...
42	...	...	...
43	...	...	...
44	...	...	...
45	...	...	...
46	...	...	...
47	...	...	...
48	...	...	...
49	...	...	...
50	...	...	...
51	...	...	...
52	...	...	...
53	...	...	...
54	...	...	...
55	...	...	...
56	...	...	...
57	...	...	...
58	...	...	...
59	...	...	...
60	...	...	...
61	...	...	...
62	...	...	...
63	...	...	...
64	...	...	...
65	...	...	...
66	...	...	...
67	...	...	...
68	...	...	...
69	...	...	...
70	...	...	...
71	...	...	...
72	...	...	...
73	...	...	...
74	...	...	...
75	...	...	...
76	...	...	...
77	...	...	...
78	...	...	...
79	...	...	...
80	...	...	...
81	...	...	...
82	...	...	...
83	...	...	...
84	...	...	...
85	...	...	...
86	...	...	...
87	...	...	...
88	...	...	...
89	...	...	...
90	...	...	...
91	...	...	...
92	...	...	...
93	...	...	...
94	...	...	...
95	...	...	...
96	...	...	...
97	...	...	...
98	...	...	...
99	...	...	...
100	...	...	...

TEAR ALONG DOTTED LINE

TYPED NAME, GRADE OR TITLE, AND TELEPHONE NUMBER

SIGN HERE:

DA FORM 2028-2 (TEST)
1 AUG 74

P.S. . . IF YOUR OUTFIT WANTS TO KNOW ABOUT YOUR MANUAL "FIND," MAKE A CARBON COPY OF THIS AND GIVE IT TO YOUR HEADQUARTERS.

AR 908236

FILL IN YOUR
UNIT'S ADDRESS

FOLD BACK

DEPARTMENT OF THE ARMY

OFFICIAL BUSINESS

Commander
US Army Armament Materiel Readiness Command
ATTN: DRSAR-MAS
Rock Island, IL 61201

FOLD BACK

TEAR ALONG DOTTED LINE

PIN : 028697-000